




Boundary

Voltage Unavailable

Voltage 0 - 99 KV

Voltage 100 - 161 KV

Voltage 220 - 287 KV

Voltage 345 KV

Voltage 500 KV

Voltage 735 KV+

Substations

Wind Turbines (permitted)